

TITO SLOT MACHINE TICKET THERMAL PAPER

Storage Instructions, Shelf Life & Archivability

Follow these simple steps
to make your product last



Storage Instructions & Shelf Life

TITO slot machine tickets may be stored up to two years from the date of shipment from Graphic Controls, if stored under the following conditions:

- Temperature: 68° F +/- 9° (20° C +/-5°)
- Relative Humidity: < 65%
- A dark location away from natural and artificial light
- In sealed packaging avoiding contact with chemicals such as plasticizers, oils, solvents, adhesives, and water

Archivability

Graphic Controls' ticket paper has a 20 year archival life of the thermally printed image if stored under the following conditions:

- Temperature: 77° F (25° C)
- Relative Humidity: < 65%
- A dark location away from natural and artificial light
- In sealed packaging avoiding contact with chemicals such as plasticizers, oils, solvents, adhesives, and water
- To achieve maximum life of any direct thermal image, the thermal product must initially be imaged to its saturated density

PLEASE NOTE:

Both Shelf Life and Archivability may be reduced by exposure to heat, humidity, excessive light or contact with chemicals such as plasticizers, oils, solvents, adhesives, and water.